

Guidelines for applying

Qeshfloor EP 6850 skirting primer

	Description	Tools/Equipment
Temperature and relative humidity (R.H.)	<ul style="list-style-type: none"> ▶ Minimum temperature in the working area: 15°C. ▶ Minimum floor temperature: 10°C and 3°C above the dew-point to prevent condensation. ▶ R.H.: maximum 85% ▶ Maximum ambient temperature: 35°C. ▶ High temperatures shorten the application time. 	<ul style="list-style-type: none"> ▶ Temperature measuring device ▶ Hygrometer ▶ Floor temperature measuring device ▶ Dew-point table
Safety measures	<ul style="list-style-type: none"> ▶ As indicated on the product label. 	<ul style="list-style-type: none"> ▶ Protective wear
Sub-floor	<ul style="list-style-type: none"> ▶ Vacuum the sub-floor using an industrial vacuum cleaner. ▶ Remove any extraneous material by sanding, grinding or blasting. ▶ Fill small holes and seams with a suitable putty. ▶ For larger repairs use Qeshfloor EP 1500 repair mortar* or UZIN NC 182 filler and levelling compound*. 	<ul style="list-style-type: none"> ▶ Industrial vacuum cleaner ▶ Blasting machine ▶ Sanding machine ▶ Putty knife ▶ Flat trowel
Mixing the primer	<ul style="list-style-type: none"> ▶ Pierce the base of the top container, so allowing component B to flow into component A. ▶ Ensure all material is transferred. ▶ Remove the top from the can. ▶ Mix using a drill with a mixer attachment that extends to the base of the container. ▶ Mix until the mixture is homogeneous. ▶ Mixing time: at least 2 minutes. ▶ In order to prevent unmixed material being used from the base/edges of the mixing vessel, transfer the mixture to a clean vessel and then mix again. 	<ul style="list-style-type: none"> ▶ Drill with mixer attachment ▶ Clean working vessel
Application of the primer	<ul style="list-style-type: none"> ▶ Apply the mixture evenly to the sub-floor in a closed layer using a brush or lamb's fleece roller. ▶ Distribute the primer so that the sub-floor is totally covered. 	<ul style="list-style-type: none"> ▶ Brush ▶ 25 cm lamb's fleece or polyester roller
Application of a second layer	<ul style="list-style-type: none"> ▶ When applying the epoxy mortar floor adopt the wet-in-wet principle. Hence do not allow the EP 6850 to fully dry. 	
Cleaning tools/equipment	<ul style="list-style-type: none"> ▶ Clean tools/equipment immediately after use with UZIN VE 124 cleaner*. 	

Qeshfloor Industrial Flooring
Industriestraat 15
P.O.box 33
7480 AA Haaksbergen
Telefoon (+31) 53 573 73 73
Fax (+31) 53 573 73 33
info@unipro.nl
www.qeshfloor.com

Qeshfloor a brand of Unipro bv

REVISIONNUMBER
guidelines EP 6850/01-11-06/rev.:0

Unipro works with a quality assurance system which conforms to the NEN-EN-ISO 9001/14001 standard and which has been certified by TÜV Nederland QA. This means that Unipro's products and services meet the specifications described in this QA system. No liability for any damage that results from the use of the product can be accepted as individual circumstances and working practices are unknown. This information leaflet nullifies earlier documentation sheets. © Unipro B.V. 2006. All rights reserved. No part of this sheet may be reproduced in any form without permission in writing from Unipro B.V.