

# Guidelines for applying

## Qeshfloor EP 7950 sealant layer

	Description	Tools/Equipment
<b>Temperature and relative humidity (R.H.)</b>	<ul style="list-style-type: none"> <li>▶ Minimum temperature in the working area: 15°C.</li> <li>▶ Minimum floor temperature: 10°C and 3°C above the dew-point to prevent condensation.</li> <li>▶ R.H.: maximum 85%.</li> <li>▶ Maximum ambient temperature: 35°C.</li> <li>▶ High temperatures shorten the application time.</li> </ul>	<ul style="list-style-type: none"> <li>▶ Temperature measuring device</li> <li>▶ Hygrometer</li> <li>▶ Floor temperature measuring device</li> <li>▶ Dew-point table</li> </ul>
<b>Safety measures</b>	<ul style="list-style-type: none"> <li>▶ As indicated on the product label.</li> </ul>	<ul style="list-style-type: none"> <li>▶ Protective wear</li> </ul>
<b>Sub-floor</b>	<ul style="list-style-type: none"> <li>▶ The mortar floor or cast floor must not be tacky and must be suitable for foot traffic.</li> <li>▶ Remove any dust or other extraneous materials.</li> </ul>	<ul style="list-style-type: none"> <li>▶ Industrial vacuum cleaner</li> </ul>
<b>Mixing the sealant layer</b>	<ul style="list-style-type: none"> <li>▶ Pour component B into component A.</li> <li>▶ Scrape the container out well to ensure all material is transferred.</li> <li>▶ Mix using a drill with a mixer attachment that extends to the base of the vessel.</li> <li>▶ Mix until homogenous.</li> <li>▶ Mixing time: at least 2 minutes.</li> <li>▶ In order to prevent unmixed material being used from the base/edges of the mixing vessel, transfer the mixture to a clean vessel and then mix again.</li> </ul>	<ul style="list-style-type: none"> <li>▶ Drill with mixer attachment</li> <li>▶ 25 litre vessel</li> </ul>
<b>Application of the sealant layer</b>	<ul style="list-style-type: none"> <li>▶ Pour the mixture onto the sub-floor and distribute with a flat trowel.</li> <li>▶ After 10 minutes roll with a saturated lamb's fleece or polyester roller.</li> </ul>	<ul style="list-style-type: none"> <li>▶ Flat trowel</li> <li>▶ 25 cm lamb's fleece or polyester roller</li> </ul>
<b>Hardening time at 20°C and 65% R.H.</b>	<ul style="list-style-type: none"> <li>▶ Suitable for foot traffic and further treatments after ca. 16 hours.</li> <li>▶ Low temperatures retard the hardening process.</li> <li>▶ Before applying a next layer we recommend lightly sanding the Qeshfloor EP 7950. Remove dust from the surface.</li> </ul>	
<b>Cleaning tools/equipment</b>	<ul style="list-style-type: none"> <li>▶ Clean tools/equipment immediately after use with UZIN VE 124 cleaner*.</li> </ul>	

Qeshfloor Industrial Flooring  
Industriestraat 15  
P.O.box 33  
7480 AA Haaksbergen  
Telefoon (+31) 53 573 73 73  
Fax (+31) 53 573 73 33  
info@unipro.nl  
www.qeshfloor.com

Qeshfloor a brand of Unipro bv

REVISIONNUMBER  
guidelines EP 7950/01-11-06/rev.:0

Unipro works with a quality assurance system which conforms to the NEN-EN-ISO 9001/14001 standard and which has been certified by TÜV Nederland QA. This means that Unipro's products and services meet the specifications described in this QA system. No liability for any damage that results from the use of the product can be accepted as individual circumstances and working practices are unknown. This information leaflet nullifies earlier documentation sheets. © Unipro B.V. 2006. All rights reserved. No part of this sheet may be reproduced in any form without permission in writing from Unipro B.V.